


Invisible Hinge Installation Instructions

All SOSS Invisible Hinges for wood are packaged with detailed installation instructions and a paper template.

A detailed instruction booklet is packaged with each Router Guide Template.

- 1 Lay the paper template on the edge of the door as shown, with the template corresponding with the mark you have made in measuring the proper distance from the top of the door.




- 2 Bend or crease the template on the scored line over the edge of the door as illustrated below. On the template are drill-point indicators. Punch a hole through the drill-point indicators to mark their location on the door.

- 3 Using a router or drill of the proper size, bore holes to required depth.

Note:


To minimize the observable gap between the door and the frame in single swing pass doors in the closed position, each half of the hinge can be mortised $1/32$ " below flush.

Start each hole at the point indicated by the hole punched through the paper template.



- 4 Using a router or chisel, remove wood to connect the holes for a smooth mortised surface.

- 5 Insert one-half of the hinge into mortise, install screws.



- 6 Repeat above steps to install hinge in jamb.

For complete instructions for installation with a router please visit our website or contact your SOSS main office. Instructions are supplied with each router guide template.