



Model DVTWBH030 (045)-E Pull Down Unit

1. IDENTIFY YOUR MODEL (300MM OR 450MM) BEFORE PROCEEDING.

2. ON PAGE 2 OF THE INSTRUCTION MANUAL, THE CUTOUT SIZE REQUIRED ON THE BASE OF THE CABINET IS NOT CLEARLY INDICATED. THE CUT OUT SIZE SHOULD BE AS FOLLOWS:
H030 -300MM MODEL - DEPTH 135MM X WIDTH 265MM
H045- 450MM MODEL – DEPTH 135MM X WIDTH

3. IN STEP 1 ON PAGE 2, IN THE DIAGRAM ON THE FAR RIGHT, THE AREAS WHERE YOU SHOULD BE DRILL MOUNTING THE HOLES ON THE BACK PANEL OR OTHER MOUNTING SURFACES FOR THE SIDE RAILS ARE NOT CLEARLY INDICATED.

4. IN STEP 2 ON PAGE 3 , SUB-STEP 2 SHOULD READ “FASTEN THE RACK TO THE REAR PANEL OR MOUNTING SURFACE USING 8 FLAT HEAD SCREWS AND THE HOLES DRILLED IN STEP 1, THEN CONNECT THE SPRING AND RACK TO EACH OTHER”.