

Fixer les rails au meuble selon la configuration choisie: 16a, 16b, 16c.

Fix the rails to the wardrobe according to your choice: 16a, 16b, 16c.

