




Pair Dimmer or Switch to smartphone or tablet



Click (+) to add a new device or (-) to delete an existing device



Basic Controls



Slide to adjust light level (-) to dim, (+) to brighten*

Tap to schedule one or multiple timed events so lights turn on and off automatically at programmed days and times

Tap to change Bulb Type, program Fade Rates*, set Minimum and Maximum light levels*, program Daylight Savings Time Options and Randomize Scheduled Events


Tap to change the device name

Slide or tap to turn light ON and OFF

Tap to set countdown timer


*Dimmer function only. Not applicable to Switch.

Scheduling Events



Click (+) to add a new event or (-) to delete an existing event

Summary of programmed events



Slide or tap to turn event ON or OFF


Select event brightness level*

Select Event Time: Sunrise, Sunset or set a specific time

Select day(s) of the week for event

**Dimmer function only. Not applicable to Switch.*

Sleep Timer



Tap Arrows to increase/decrease time

OR

Tap for a preset time

Visit our Website at: www.leviton.com/decoradigital

© 2015 Leviton Manufacturing Co., Inc. All rights reserved.
All trademarks are the property of their respective owners.



App Store, Google Play and the Bluetooth word marks and logos are the registered trademarks of Apple Inc., Google Inc. and Bluetooth SIG, Inc., respectively, and any use of such marks by Leviton is under license. All other third party trademarks are the property of their respective owners.