



## **CLIP top Hinge 170°**

**Product #** 71T668180

**Fixing Type** Dowel

**Use Type** Bi-Fold Door

**Cabinet Type** Frameless

**Closing Mechanism** Spring Closing

**Door Position** Half Overlay

**Milling Depth** 13/32 in\*

**Packaging format** Per unit

### **DESCRIPTION**

CLIP top hinges are concealed hinges for cabinet doors, meaning they cannot be seen when the door is closed. These hinges are easy to use and they work in almost any hinge application because of the wide variety of mounting plates available. These Euro hinges can be used in frameless and face frame cabinets. CLIP top hinges can also be easily upgraded with soft closing BLUMOTION making them a flexible and reliable option for any cabinet.

### **ADVANTAGES AND BENEFITS**

-Tool-free assembly -Easy three-dimensional adjustment

## REQUIRED PRODUCTS

Requires ONE of the following products

Sales unit



### BLUM Mounting Plate

Product # 173L810180

Fixing Type: Pre-mounted Euro  
Screw

OR



### BLUM Mounting Plate

Product # 174E610180

Fixing Type: Expanding  
Dowel

OR



### BLUM Mounting Plates with Adjusting Cam

Product # 174H710180

OR



### Mounting Plate with Horizontal Cam

Product # 177H310E180

## TECHNICAL SPECIFICATIONS

Product #	71T668180
Hinge Type	CLIP top
Cabinet Thickness	Min. 5/8 in*
Door Thickness	Min. 5/8 in*
Milling Diameter	1 3/8 in*
Hinge Opening Angle	+170°
Brand	Blum
Material	Steel, Zamac

### Disclaimer

Measures shown with an asterisk (\*) have been converted as per your preference. These are not the official measures. To view the measures specified by the manufacturer, [click here](#).

---

## IMPORTANT INFORMATION

The best way to clean your Blum fittings is as follows: - Use a soft, lint-free cloth, a chamois leather or a sponge - Ensure that the material you use to wipe the furniture with is just damp, not wet - Always wipe the furniture again afterwards with a dry cloth - If possible, use cleaning products intended specifically for materials such as leather, stainless steel etc.; otherwise, use only clean water - Wipe off dirt as soon as it appears AVOID THE FOLLOWING: - using steam cleaners - using cleaning products, such as abrasive cleaning powder, steel wool and scourers, as well as cleaning agents, such as acetone, chlorine, cellulose thinner and solutions whose names start with tri or tetra - storing open cleaning products, baking powder, dishwasher products or table salt, for example. Fumes can cause corrosion on all metal surfaces.

## APPLICATION

- For the installation of a door on a piece of furniture and/or a cabinet. - Blum hinges are not made of stainless steel, therefore it is not recommended to use them for outdoor applications.

## PRODUCT PHOTOS

