



Saw Cleaner

Product # D010355

DESCRIPTION

Works in minutes to clean pitch and gum from saws, router bits, and shaper cutters.

This effective cleaner is safe to use on carbide, high speed steel, stainless steel, and cast-iron surfaces.

Hold can upright and point spray button away from face. SHAKE WELL, then spray saw from a distance of 8 to 12 inches (20-31 cm) to give it an even coating. Allow to stand about 5 minutes. Wipe clean with a damp cloth, sponge, or paper towel. Spots that are difficult to remove should be re-treated and cleaned with a scouring pad. After cleaning, be sure to spray or wipe with oil to prevent rust.

TECHNICAL SPECIFICATIONS

Product #	D010355
Format	18 oz
Brand	Richelieu

PRODUCT PHOTOS

