



Industrial Sliding System for Wall Mounting C-911/C-108

Product # WEBKIT1000254

DESCRIPTION

Quick-release hanger

The Spinwheel hanger permits fast and easy door removal from the outside, whether or not a door is locked. (For example, the door can be removed to reach a patient in distress in a washroom who requires immediate assistance.)

ADVANTAGES AND BENEFITS

Leveling and height adjustment can be accomplished by one person during door installation without the need for tools.

INCLUDED IN THIS WEBKIT

Sales unit

Guide C-200
Product # KNC200



Sliding Door Stopper/Keeper
Product # KNCDC911





Quick-Release Hanger, C-911
Product # KN911




REQUIRED PRODUCTS!


Requires ONE of the following products

	Sales unit
<div>  <div> <p>Wall Mounting Aluminum Track C-108</p> <p>Product # KNC10872</p> <p>Overall Length: 72 in</p> </div> </div>	Length of 6 linear foot
OR	

<div>  <div> <p>Wall Mounting Aluminum Track C-108</p> <p>Product # KNC10896</p> <p>Overall Length: 96 in</p> </div> </div>	Length of 8 linear foot
--	-------------------------

Requires ONE of the following products

	Sales unit
<div>  <div> <p>Recessed Bottom Guiding Track C-201</p> <p>Product # KNC201144</p> <p>Overall Length: 12 ft</p> </div> </div>	Length of 12 linear foot
OR	

<div>  <div> <p>Recessed Bottom Guiding Track C-201</p> <p>Product # KNC20196</p> <p>Overall Length: 8 ft</p> </div> </div>	
---	--

TECHNICAL SPECIFICATIONS

Product #	WEBKIT1000254
Door Material	Wood
Door Movement	Straight Sliding
Track Mounting	Wall Mount
Load Capacity	Max. 200 lb
Door Position	In Front of Wall
Door Thickness	1 3/8 to 1 3/4 in
Roller Type	Ball Bearing
Roller Position	Upper
Application	Closet and Walk-In Closet, Screen Panel
Brand	K.N. Crowder
Overall Length	72 to 96 in
Manufacturing Material	Aluminum
Finish	Mill Finish
Groove Needed for Guiding System	Yes
Number of Doors	1

APPLICATION

An essential safety feature for nursing homes and hospitals.

IMPORTANT INFORMATION

Requires a minimum clearance of 1/2" between door and fascia for disengagement. - Pictures provided for visual reference only: actual product may vary. - All required hardware should be ordered and obtained prior to initiating fabrication or installation work. Please verify that the parts and quantities listed in your order are correct before proceeding to checkout. - Always use instructions provided by the manufacturer, as included with the product. Manufacturer reserves the right to amend, modify, or otherwise supplement any previously issued product and/or technical information, as deemed required from time to time, without prior notice. - The documentation, drawings, and instructions on this page apply to the system described on this page only. Richelieu expressly declines all responsibility for any design or construction that combines this system with systems from this same manufacturer or systems from other manufacturers. - Installation of the product shall be executed by qualified individuals only, always ensuring that each product is securely installed using proper fixation methods, as appropriate for each applicable substratum. We trust that anyone installing these products has the required skills, knowledge, and experience. Richelieu expressly disclaims any liabilities for results obtained through improper use or installation. - Always remove debris/dust/residues (sawdust and/or aluminum) from all tracks and guide channels using a dry cloth during installation and before operating the system. - Never spray lubricant.

DISCLAIMER

By accessing or referring to this document, or by using any of Richelieu's websites, you accept all applicable terms as they apply from time to time. This legal disclaimer is in no way limited or altered by any other terms or conditions. Richelieu may change said terms at its discretion and without prior notice. A version of the most current terms will always be available on Richelieu's website. The preceding information and technical documentation, information, or recommendations issued by Richelieu verbally or in writing is believed to be accurate and is given in good faith, but no representation of warranty as to its completeness or accuracy is made. Suggestions for use or application are only opinions. Users are responsible for determining the suitability of these products for their own particular purpose. No representation of warranty, expressed or implied, is made with respect to information or products including, without limitation, warranties or merchantability, fitness for particular purpose, non-infringement of any third party patent or other intellectual property rights including, without limit, copyright, trademark, and designs. Any trademarks identified herein are trademarks of the Richelieu group of companies. Richelieu assumes no risk and shall not be subject to any liability for damages or loss resulting from the specific use or application made of the product. Richelieu's liability for any claim, whether based on breach of contract, negligence, or infringement of any rights of any party relating to the product shall not exceed the price paid for said products. In no event shall Richelieu be liable for any special, incidental, or consequential damages (including loss of use, loss of profit, and claims of third parties) however caused, whether by the negligence of Richelieu or otherwise. Products returned for warranty purposes shall be subject to Richelieu's then applicable Return Policy.

PRODUCT PHOTOS

