



HAWA Porta 100 GM Ceiling Mount Sliding Glass Door System

Application

Closet and Walk-In Closet / Screen Panel / Glass Partition Closet and Walk-In Closet / Screen Panel / Glass Partition / Bathroom

DESCRIPTION

Glass flush with track

The HAWA Porta 100 GM is a top hung sliding system for frameless glass door panels weighing up to 200 lb (90.7 kg) each. The glass is held at the top by two glass clamp shoes without drilling and adhesive. The upper track can be recessed or surface mounted to the ceiling. A clip-on fascia panel clip is quick and simple to install to the clamping shoes for a clean finish.

ADVANTAGES AND BENEFITS

- Minimal installation height - Glass mounts with well-tested clamp technology - For ceiling mounting - Running gear concealed behind design fascia - Continuous bottom guide adjustment for different glass thicknesses

AVAILABLE PRODUCTS

Product #	Application
WEBKIT1004081	Closet and Walk-In Closet / Screen Panel / Glass Partition
WEBKIT1004080	Closet and Walk-In Closet / Screen Panel / Glass Partition / Bathroom



TECHNICAL SPECIFICATIONS

Door Material	Glass
Door Movement	Straight Sliding
Detailed Door Movement	Single sliding
Track Mounting	Ceiling Mount, Recessed - Inside Ceiling
Load Capacity	Max. 220 lb*
Door Position	Concealed Inside Wall, In Front of Wall
Door Thickness	5/16 to 1/2 in*
Roller Type	Ball Bearing
Roller Position	Upper
Brand	Hawa
Overall Length	98 3/8 in*
Manufacturing Material	Aluminum
Finish	Satin Aluminum
Soft-Closing	Yes
Soft-Close Type	One-Way Operation
Number of Doors	1
Door Height	Max. 8 ft 10 in*
Door Width	Max. 48 in*

Disclaimer

Measures shown with an asterisk (*) have been converted as per your preference. These are not the official measures. To view the measures specified by the manufacturer, <u>click here</u>.

APPLICATION

- All-glass doors - Private living areas - Private and public office areas - Projects - Personalized interior design

IMPORTANT INFORMATION

For soft closing in both directions, add the following products to your order: 893102071 and 89311407. The center-to-center distance between rollers should be 570 mm. - Pictures provided for visual reference only: actual product may vary. - All required hardware should be ordered and obtained prior to initiating fabrication or installation work. Please verify that the parts and quantities listed in your order are correct before proceeding to checkout. - Always use instructions provided by the manufacturer, as included with the product. Manufacturer reserves the right to amend, modify, or otherwise supplement any previously issued product and/or technical information, as deemed required from time to time, without prior notice. - The documentation, drawings, and instructions on this page apply to the system described on this page only. Richelieu expressly declines all responsibility for any design or construction that combines this system with systems from this same manufacturer or systems from other manufacturers. - Installation of the product shall be executed by qualified individuals only, always ensuring that each product is securely installed using proper fixation methods, as appropriate for each applicable substratum. We trust that anyone installing these products has the required skills, knowledge, and experience. Richelieu expressly disclaims any liabilities for results obtained through improper use or installation. - Always remove debris/dust/residues (sawdust and/or aluminum) from all tracks and guide channels using a dry cloth during installation and before operating the system. - Never spray lubricant.



DISCLAIMER

By accessing or referring to this document, or by using any of Richelieu's websites, you accept all applicable terms as they apply from time to time. This legal disclaimer is in no way limited or altered by any other terms or conditions. Richelieu may change said terms at its discretion and without prior notice. A version of the most current terms will always be available on Richelieu's website. The preceding information and technical documentation, information, or recommendations issued by Richelieu verbally or in writing is believed to be accurate and is given in good faith, but no representation of warranty as to its completeness or accuracy is made. Suggestions for use or application are only opinions. Users are responsible for determining the suitability of these products for their own particular purpose. No representation of warranty, expressed or implied, is made with respect to information or products including, without limitation, warranties or merchantability, fitness for particular purpose, non-infringement of any third party patent or other intellectual property rights including, without limit, copyright, trademark, and designs. Any trademarks identified herein are trademarks of the Richelieu group of companies. Richelieu assumes no risk and shall not be subject to any liability for damages or loss resulting from the specific use or application made of the product. Richelieu's liability for any claim, whether based on breach of contract, negligence, or infringement of any rights of any party relating to the product shall not exceed the price paid for said products. In no event shall Richelieu be liable for any special, incidental, or consequential damages (including loss of use, loss of profit, and claims of third parties) however caused, whether by the negligence of Richelieu or otherwise. Products returned for warranty purposes shall be subject to Richelieu's then applicable Return Policy.

PRODUCT PHOTOS



